

# 2013

## APPLICATION GUIDE



Toll-free: 1-888-945-5725 | Tel: (905) 827-0224 | Fax: (905) 827-2357 | www.willpak.com

### *We've got your louver and it's COOL again.*

#### ABS [Textured] Truck Rear Window Louvers: Low Profile Design

Part Number	Model Years	Model	Description
<b>CHEVROLET / GMC</b>			
6062	1999-2006	Full Size	Fits non-sliding window, Flat Hardware, Full Louver across window
<b>DODGE</b>			
6063	2002-2007	Ram (not Quad Cab)	Fits non-sliding window, Flat Hardware, Full Louver across window
8063	2002-2007	Ram (not Quad Cab)	Fits sliding window, Flat Hardware, Full Louver across window
<b>FORD</b>			
6064	2004-2013	F-150	Fits non-sliding window, Flat Hardware, Full Louver across window
8064	2004-2013	F-150	Fits sliding window, Flat Hardware, Full Louver across window
6061	1997-2003	F-150	Fits non-sliding window, Flat Hardware, Full Louver across window
8061	1997-2003	F-150	Fits sliding window, Flat Hardware, Full Louver across window

#### ABS [Textured] Truck Rear Window Louvers: Classic Style Design

Part Number	Model Years	Model	Description
<b>CHEVROLET / GMC</b>			
3020	1973-1987	Full Size	Non-Sliding Window, No Hardware, Full Louver across window
5039	1988-1993	Full Size	Sliding Window, Hinged Hardware, Center Opening
	1994-1998	Full Size Extended Cab	
6028	1988-1993	Full Size	Non-Sliding Window, Hinged Hardware, Full Louver across window
	1994-1998	Full Size Extended Cab	
	1994-1998	Full Size Regular Cab	
8039	1988-1993	Full Size	Sliding Window, Hinged Hardware, Full Louver across window
	1994-1998	Full Size Extended Cab	
6060	1999-2006	Full Size	Non-Sliding Window, Hinged Hardware, Full Louver across window

8060	1999-2006	Full Size	Sliding Window, Hinged Hardware, Full Louver across window
3111	1982-1993	S10	Non-Sliding Window, No Hardware, Full Louver across window
	1991-1993	Sonoma	
3135	1994-2003	S10 / Sonoma	Non-Sliding Window, Dual Lock Tape Supplied, Full Louver across window
5049	1994-2003	S10 / Sonoma	Sliding Window, Hinged Hardware, Center Opening
6039	1994-2003	S10 / Sonoma	Non-Sliding Window, Hinged Hardware, Full Louver across window
8049	1994-2003	S10 / Sonoma	Sliding Window, Hinged Hardware, Full Louver across window
3139	1988-1993	Full Size	Non-Sliding Window, Dual Lock Tape Supplied, Full Louver across window
	1994-1998	Full Size Extended Cab	
	1994-1998	Full Size Regular Cab	
<b>DODGE</b>			
3123	1986-1996	Dakota	Non-Sliding Window, No Hardware, Full Louver across window
6055	1997-2010	Dakota (all sizes)	Non-Sliding Window, Hinged Hardware, Full Louver across window
8055	1997-2010	Dakota (all sizes)	Sliding Window, Hinged Hardware, Full Louver across window
3137	1994-1997	Ram Club Cab	Non-Sliding Window, Dual Lock Tape Supplied, Full Louver across window
	1994-1997	Regular Cab	
6040	1998-2001	Ram Club Cab	Sliding Window, Hinged Hardware, Full Louver across window
	1994-1997	Regular Cab	Non-Sliding Window, Hinged Hardware, Full Louver across window
8058	1998-2001	Ram Club Cab	Sliding Window, Hinged Hardware, Full Louver across window
	1998-2001	Regular Cab	
<b>FORD</b>			
3010	1975-1996	F-150 (all sizes)	Non-Sliding Window, No Hardware, Full Louver across window
6001	1975-1996	F-150 (all sizes)	Non-Sliding Window, Hinged Hardware, Full Louver across window
6054	1997-2003	F-150 (all sizes)	Non-Sliding Window, Hinged Hardware, Full Louver across window
8054	1997-2003	F-150 (all sizes)	Sliding Window, Hinged Hardware, Full Louver across window
8024	1984-1996	F-150 (Factory Installation Window only)	Sliding Window, Hinged Hardware, Full Louver across window, Factory Installation window only
6013	1982-1992	Ranger	Non-Sliding Window, Hinged Hardware, Full Louver across window
8009	1982-1992	Ranger	Sliding Window, Hinged Hardware, Full Louver across window
3133	1993-1997	Ranger	Non-Sliding Window, No Hardware, Full Louver across window
6037	1993-1997	Ranger	Non-Sliding Window, Hinged Hardware, Full Louver across window
8047	1993-1997	Ranger	Sliding Window, Hinged Hardware, Full Louver across window
3134	1998-2010	Ranger (all sizes)	Non-Sliding Window, No Hardware, Full Louver across window
6038	1998-2013	Ranger (all sizes)	Non-Sliding Window, Hinged Hardware, Full Louver across window
8048	1998-2013	Ranger (all sizes)	Sliding Window, Hinged Hardware, Full Louver across window
5056	1999-2007	F-250 / 350 / 450 Superduty	Sliding Window, Hinged Hardware, Center Opening
6056	1999-2007	F-250 / 350 / 450 Superduty	Non-Sliding Window, Hinged Hardware, Full Louver across window
8056	1999-2007	F-250 / 350 / 450 Superduty	Sliding Window, Hinged Hardware, Full Louver across window
<b>MAZDA</b>			
3134	1994-2010	Super Cab	Non-Sliding Window, No Hardware, Full Louver across window
	1998-2010	All	
6038	1994-2010	Super Cab	Non-Sliding Window, Hinged Hardware, Full Louver across window
	1998-2010	All	
8048	1994-2010	Super Cab	Sliding Window, Hinged Hardware, Full Louver across window
	1998-2010	All	

NISSAN			
3121	1986-1998	Regular Cab King Cab	Non-Sliding Window, No Hardware, Full Louver across window
3116	1984-1988	Toyota King Cab	Non-Sliding Window, No Hardware, Full Louver across window
ABS [Textured] Van Rear Window Louvers			
Part Number	Model Years	Model	Description
CHEVROLET / GMC			
2001	1971-1996	Full-Size Van	Non-Pop Out Window (fixed), installs with Dual Lock Tape
2005	1971-1996	Full-Size Van	Pop Out Window, installs with Dual Lock Tape
10449	1971-1996	Full-Size Van	Non-Pop Out Window (fixed), installs with Dual Lock Tape, Smooth surface, must be painted before application to van
10450	1971-1996	Full-Size Van	Pop Out Window, installs with Dual Lock Tape, Smooth surface, must be painted before application to van
2011	1985-2006	Astro / Safari (not Dutch Doors)	Non Pop Out Window (fixed), installs with Hardware
2013	1985-2006	Astro / Safari (not Dutch Doors)	Pop Out Window, installs with Hardware
2029	1997-2013	Express / Savana	Non Pop Out Window (fixed) and Pop Out Window, installs with Hardware
DODGE			
2008	1978-2005	Full-Size Van	Non Pop Out Window (fixed), installs with Dual Lock Tape
2009	1978-2005	Full-Size Van	Pop Out Window, installs with Dual Lock Tape
FORD			
2002	1971-1974	Full-Size Van	Non Pop Out Window (fixed), installs with Dual Lock Tape
2003	1975-1991	Full-Size Van	Non-Pop Out Window (fixed), installs with Dual Lock Tape
2007	1975-1991	Full-Size Van	Pop Out Window, installs with Dual Lock Tape
2028	1992-2013	Econoline	Non Pop Out Window (fixed) and Pop Out Window, installs with Hardware